

## Nivåvakt tömning (röd) och påfyllning (orange)


Det är viktigt att du läser bruksanvisningen innan du använder produkten för din säkerhet. Spara den också för framtida behov.

**Detta är en förkortad version av originalbruksanvisningen översatt till svenska av Vattenliv.**

Denna produkt hjälper dig att hålla vattnet i en viss nivå genom att den slår av eller på något för att hålla vattennivån. Sensorn i den hjälper till med detta och den fungerar även med andra vätskor än vatten.

## Installation

Modellerna vi säljer är färdig installerade för att sätta i ett eluttag och sen sätter du kontakten till, oftast, pumpen i nivåvakten. Fäst avkännaren där det passar för den funktion som ska uppnås. Nedan bild visar när den reagerar beroende på om du vill tömma eller fylla.



In emptying mode the device activates the relay when the liquid reaches the high level.

The relay is deactivated when the liquid goes down below the low level.

**NOTE.** the device can be requested for emptying or filling application. in the filling mode the functions are inverted so that the motor stops once the high level has been reached.

**Warning:** this device **CAN NOT** be used in dirty water with solid debris, oil, fats and so on

## Underhåll och rengöring

Rengör delen som känner av nivån så att inte smuts gör att den inte känner av nivån.